



# FOREVER REDWOOD

*From the Forest, For the Forest since 1995*








---

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

## ASSEMBLY INSTRUCTIONS FOR THE CHAIR SWING SETS








CONTENT OF BOXES - Frame Swing			
Qty.	Description	Drawing	No.
2	Posts		1
2	Legs		2
1	Supports		3
4	Diagonal Supports		4
4	Roof Supports If ordered		5
2	Roof Frame If ordered		6
1	Roof Board If ordered		7

**Note:** Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.















CONTENT OF BOXES – Chair Swing				
Qty.	Description	Drawing	No.	
1	Seat		8	
1	Backrest		9	
2	Armrest		10	

**Note:** Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.






HARDWARE LIST		
Description	Drawing	No.
3/8" X 7" Bolts (To attach the posts to the legs).		A
3/8" X 11" Bolts (To attach the posts to the legs).		B
5/16" X 3 1/2" Bolts (To attach the support to the posts. / To attach the seat and the backrest to the armrest).		C
3/8" X 8" Bolts (To attach the diagonals supports to the posts and to the support).		D
5/16" X 5 1/2" Bolts (To attach the roof supports to the posts).		E
5/16" X 4" Bolts (To attach the roof panels to the roof supports).		F
3" Deck Screw (To attach the roof panels to the diagonal supports).		G
2" Deck Screw (To attach the roof board to the post).		H
3/8" X 4" Eyebolts (To attach the backrest to the armrest).		I
Quick Links		J
Springs		K
Chains		L

**Note:** Dimensions of your hardware will vary depending on size.






DESCRIPTION	No
Posts	1
Legs	2
Supports	3
Diagonal Supports	4
Roof Supports	5
Roof Frame	6
Roof Board	7
Seat	8
Backrest	9
Armrest	10

**Note:** Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.




## Option A – Without Swing Roof

**Step 1:** Attach the post (1) to the legs (2) with 3/8" x 7" bolts (A) and 3/8" x 11" bolts (B). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 2:** Put the Quick Links (J) and the Springs (K) in the hanger's support. After that, put the chains (L). Take a few minutes to adjust the chain height to your preference.






**Step 3:** Use 5/16" x 3 1/2" bolts (C) to attach support (3) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 4:** Attach the diagonal supports (4) to the posts and to the support with 3/8" x 8" bolts (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




***Note:*** If your Swing Set doesn't include roof, then go to **step 8**.

## Option B – With Swing Roof

**Step 5:** Attach the roof supports (5) to the posts with 5/16" x 5 1/2" bolts (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 6:** Attach the roof panels (6) to the roof supports with 5/16" x 4" bolts (F) and to the diagonal supports with 3" deck screws (G). Each part has a series of numbers that indicate where to attach the part with the corresponding number.







**Step 7:** Use 2" deck screws (H) to attach the roof board (7) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 8:** Attach the seat (8) to the armrest (10) with 5/16" x 3 1/2" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 9:** Attach the backrest (9) to the armrest (10) with 5/16" x 3 1/2" bolts (C) and 3/8" x 4" eyebolts (I). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 9:** Finally, use quick links (J) to joining the chair swing to the chains (L).



**Option A – Without Swing Roof**



**Option B – With Swing Roof**







*This completes the Swing assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.*