

---

866.332.2403; Outside the US: 619.600.5630 7am-7pm Pacific Time, Monday-Saturday





## Assembly Instructions for: **CHAIR SWINGS (SEATS ONLY)**



Thank you for purchasing Forever Redwood patio furniture. Forever Redwood is built by Old-Growth Again Restoration Forestry (OGA). OGA is dedicated to restoration forestry. Sales of patio furniture finance our restoration work in California redwood forestlands.

**Tools required:** ½-inch ratchet and a mallet or small hammer.

**Content of Boxes:**

<b>Seat</b>		
		
Quantity	Description	Drawing
1	Seat (J1)	
2	Arms (L1, L2)	
2	Backrest (N1)	


**Hardware:**

Quantity	Description
2	Chains
2	Springs
12	Quick Links
10	3 ½" x 5/16" Bolts, washers and nuts
2	Eyebolts 4" x 3/8"

The parts that go together have the same numbers written next to the predrilled holes they attach to. Align the parts with the numbers as shown for ease of reference.


**Step 1:**

Attach seat sides to seat with 4 bolts, washers and nuts per side. Make sure the numbers next to the predrilled holes match.



**Step 2:**

Attach backrest to seat sides with 1 eyebolt and 1 bolt, washers and nuts per side.





**Step 3:**

Add the chain to the swing seat. Add the hardware provided to thread the eyebolts as shown below. Take a few minutes to adjust the chain height to your preference. We recommend you do not cut off the excess chain because you may want to readjust the heights later.



Thank you! If you have any questions, please call or email us.