
866.332.2403; Outside the US: 619.600.5630 7am-7pm Pacific Time, Monday-Saturday





Assembly Instructions for: **TODDLER'S RECTANGULAR PICNIC TABLES**



Thank you for purchasing Forever Redwood patio furniture. Forever Redwood is built by Old-Growth Again Restoration Forestry (OGA). OGA is dedicated to restoration forestry. Sales of patio furniture finance our restoration work in California redwood forestlands.


Tools required: 1/2 inch ratchet and a mallet or small hammer.

Content of Boxes:



Quantity	Description	Drawing
1	Tabletop	
2	Benches	
2	Legs	
2	Diagonal Supports	
8	8 x 3 Screws – To attach diagonal supports	
12	5/16" x 3 1/2" Carriage Bolts, washers and nuts	

The parts that go together have the same numbers written next to the predrilled holes they attach to. Align the parts with the numbers as shown for ease of reference.


Step 1: Place the tabletop upside down on carpeting or some other soft surface so that the tabletop is not scratched in the assembly process. Attach legs to tabletop with 2 carriage bolts, washers and nuts each. Match up the numbers to each corresponding side. Align the leg to the predrilled holes, tap the bolts in, add a washer and tighten the nut. The legs are not interchangeable from side to side. Make sure you are attaching the correct side.



Step 2: Attach the diagonal support to leg and tabletop as shown below with 2 deck screws per side. Match the numbers written on it with the numbers on the leg. Repeat the process for the other diagonal support piece. Then carefully turn the table around. It is best to turn the table over with two persons to avoid any damage.



Step 3: Attach benches to legs with 2 carriage bolts, washers and nuts per side. Match the numbers written next to the predrilled holes.



Thank you for supporting our work. If you have any questions, please call or email us.