

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

ASSEMBLY INSTRUCTIONS FOR THE HERITAGE WOODEN PICNIC BENCH




	No.	-	7	3
CONTENT OF BOXES	Drawing			
	Description	Seat	Legs	Diagonal Supports
	Qty.	-	2	2

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.


Note: Dimensions of your hardware will vary depending on size.

DESCRIPTION	No
Seat	П
Legs	2
Diagonal Supports	3




Note: Part numbers in the <u>Drawing</u> are for reference only. These do not match to the numbers marked on the parts sent.

Step 1: Place the bench upside down. After that, attach the legs (2) to the seat (1) with 5/16" x $3\frac{1}{2}$ " bolts (A). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 2: Use 5/16" x 3 ½" bolts (**A**) to attach the diagonal supports (**3**) to the bench and to the seat. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 3: Finally, turn the bench over its feet.



This completes the Bench Assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.