




FOREVER REDWOOD




From the Forest, For the Forest since 1995

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday



ASSEMBLY INSTRUCTIONS FOR THE **LIGHTHOUSE GARDEN BENCH**






CONTENT OF BOXES			
Qty.	Description	Drawing	No.
1	Seat		1
2	Legs		2
2	Diagonal Supports		3

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.

HARDWARE LIST		
Description	Drawing	No.
5/16" X 3 1/2" Bolts (To attach the legs to the seat).		A
2 1/2" Deck Screws (To attach the diagonal supports to the seat and to the legs).		B


Note: Dimensions of your hardware will vary depending on size.




DESCRIPTION	No
Seat	1
Legs	2
Diagonal Supports	3

Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.


Step 1: Place the seat upside down. After that, use 5/16" x 3 1/2" bolts (A) to attach the legs (2) to the seat (1). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 2: Attach the diagonal supports (3) to the seat and to the legs with 2 1/2" deck screws (B). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 3: Turn the Bench over is feet.



This completes the Bench Assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.