








FOREVER | REDWOOD

From the Forest, For the Forest since 1995

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday




ASSEMBLY INSTRUCTIONS FOR THE OCTAGONAL PICNIC TABLE (ATTACHED BENCHES)




CONTENT OF BOXES			
Qty.	Description	Drawing	No.
1	Tabletop		1
4	Legs		2
4	Cross Supports		3
8	Diagonal Supports		4
4	Benches		5

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.



CONTENT OF BOXES		
Description	Drawing	No.
3/8" X 6 1/2" Bolts (To attach the legs to the tabletop /To attach the cross supports to the legs. /To attach the benches to the cross supports).		A
5/16" X 5 1/2" Bolts (To attach the diagonal supports to the legs).		B
5/16" X 3 1/2" Bolts (To attach the diagonal supports to the benches).		C


Note: Dimensions of your hardware will vary depending on size.




DESCRIPTION	No
Tabletop	1
Legs	2
Cross Supports	3
Diagonal Supports	4
Benches	5

Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.


Step 1: Place the tabletop upside down. After that, attach the legs (2) to the tabletop (1) with 3/8" x 6 1/2" bolts (A). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 2: Use 3/8" x 6 1/2" bolts (A) to attach the cross supports (3) to the legs. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 3: Turn the table over its feet. After that, attach the benches (5) to the cross supports with 3/8" x 6 1/2" bolts (A). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 4: Finally, use 5/16" x 5 1/2" (B) bolts to attach the diagonal supports (4) to the legs. After that, attach the diagonal supports (4) to the benches with 5/16" x 3 1/2" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.





This completes the Picnic Table assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.