


866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

## ASSEMBLY INSTRUCTIONS FOR THE **TERRACE ROUND WOODEN TABLE**






Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.

	HARDWARE LIST	
Description	Drawing	No.
$5/16^{\prime\prime} \times 3^{1/2}$ Bolts (To attach the tabletop to the legs).		A
$5/16^{\prime\prime} \times 6^{1/2}$ Bolts (To attach the tabletop to the legs).		В


Note: Dimensions of your hardware will vary depending on size.

DESCRIPTION	No
Tabletop	1
Legs	2



Note: Part numbers in the <u>Drawing</u> are for reference only. These do not match to the numbers marked on the parts sent.

**Step 1:** Place the tabletop upside down. After that, use  $5/16^{\prime\prime} \times 3 \frac{1}{2}^{\prime\prime}$  bolts (**A**) and  $5/16^{\prime\prime} \times 6 \frac{1}{2}^{\prime\prime}$  bolts (**B**) to attach each leg (**2**) to the tabletop (**1**). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 2:** Finally, turn the table over its feet.





This completes the Table assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.