


866.332.2403; Outside the US: 619.600.5630 7am-7pm Pacific Time, Monday-Saturday

Assembly Instructions for: **BENCH FOR OCTAGONAL PICNIC TABLES**



Content of boxes:



The parts that go together have the same numbers written next to the predrilled holes they attach to. Align the parts with the numbers as shown for ease of reference.

STEP 1:

Attach the leg to the bench top, with two bolts (3/8" x 3 1/2"), washers & nuts (into two holes marched "1"). Tap the bolt all the way into the wood to set it. Then add a washer and nut and lightly tighten.





STEP 2: Repeat step 1 with the other leg.



STEP 5:

Attach the diagonal supports to the legs and bench top, with 2 bolts each, washers & nuts. Tap the bolt all the way into the wood to set it. Then add a washer and nut and lightly tighten.

Repeat this step with the other diagonal supports.



Thank you. If you have any questions, please call or email us.