






866.332.2403 (TOLL FREE) (707) 640.29.05 (Option 4) Direct Line for the Design Department; 7am – 7pm Pacific Time, Monday-Saturday

## **ASSEMBLY INSTRUCTIONS FOR THE DEL NORTE OUTDOOR KITCHEN PAVILION**




**NOTE:** Assembly is best done by two people. To assemble your product, you need a Hammer, a Ratch or a wrench and if required a Drill.




**Required Tools (Are not included in your hardware packing).**

**PROCESS TO INSTALL THE HARDWARE PROVIDED.**



**To install the bolts.**


Insert the carriage bolts into the holes and lightly tap with a hammer until the square neck fit in the wood piece and the bolt head must flush with the wood piece. Finally, place the washer and the nut and carefully tighten it using a ratch with the necessary socket or a wrench.



**To install the lag bolts.**














Place the washers in their lag bolts. After that, insert the lag bolts into the holes and carefully tighten it using a **ratch** with the necessary **socket**.

**Use the washers only for the Wood Pieces.**













**To install the deck screws.**

Insert the deck screws into the holes and carefully tighten it using a drill.

CONTENT OF BOXES		
Description	Drawing	No.
Posts		1
Single Supports		2
Supports with In-Between Blocking		3
Roof Trusses		4
Roof panel		5
Roof trims		6
Main Knee Braces		7
Secondary Knee Braces		8
Boot		9
Fascias		10
Ceiling fan base		11
Metal plaques		12
High Wind Anchor Base		13


**Note:** Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.

HARDWARE LIST			
Qty.	Description	Drawing	No.
36	5/16" x 3" Lag Bolts		LB1
24	3/8" x 3" lag bolts		LB2
54	3/8" x 6 1/2" bolts		BL1
10	3/8" X 9" Bolts		BL2
2	3/8" X 12" Bolts		BL3
16	3/8" x 8" bolts		BL4
24	3/8" x 9 1/2" bolts		BL5
4	3/8" x 10" bolts		BL6
300	2" deck screws		DS1
30	3" deck screws		DS2

*Note: Dimensions of your hardware will vary depending on size.*

<b>DESCRIPCION</b>	<b>No.</b>
Posts	1
Single Supports	2
Supports with In-Between Blocking	3
Roof Trusses	4
Roof panel	5
Roof trims	6
Main Knee Braces	7
Secondary Knee Braces	8
Boot	9
Fascias	10
Ceiling fan base	11
Metal plaques	12
High Wind Anchor Base	13






**Note:** Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.

**NOTE:** In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).


**Note:** Before install the anchor bases make sure that the ground is level using a carpenter's level or hydro-level (water level).

**Step 1:** Install the Anchor Bases (13). Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases. Drill a  $\phi \frac{1}{4}$ ” hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use 5/16” x 3” Lag Bolts (LB1) to attach each post to its respective anchor base.




**Step 2:** Attach the single supports (2) to the posts with 3/8” x 6 1/2” bolts (BL1) with washer and nuts. Check the marked numbers on each support and place as drawings shown.

Note: Don’t completely tighten yet the bolts – you will need the install the supports with in between blocking first.







**Step 3:** Attach the single supports to the supports with in-between blocking (3), use 3/8" x 6 1/2" bolts (BL1) with washer and nuts. After that, return to the bolts described in the step 2 and tighten fully. Check the marked numbers on each support with in-between blocking and place as drawings shown.




**Step 4:** Attach the main knee braces (7) to the supports with 3/8" x 6 1/2" bolts (BL1) and to the posts with 3/8" X 9" Bolts (BL2) with washer and nuts. Check the marked numbers on each main knee brace and place as drawings shown.



**Step 4:** Attach the central knee braces (7) to the supports with 3/8" x 6 1/2" bolts (BL1) and to the posts with 3/8" X 12" Bolts (BL3) with washer and nuts. Check the marked numbers on each main knee brace and place as drawings shown.




**Step 5:** Attach the metal plaques (12) to the supports with 3/8" x 3" lag bolts (LB2).




**Step 6:** Attach the perimeter Roof Trusses (4) to the posts with 3/8" x 6 1/2" bolts (BL1) with washer and nuts to attach the roof trusses (4) to the supports. Check the marked numbers on each roof truss and place as drawings shown.

*Note: repeat this step.*


*Note: place the roof trusses from back to front.*




**Step 7:** Attach the roof trusses (4) to the metal plaques with 3/8" x 3" lag bolts (LB2). Check the marked numbers on each roof truss and place as drawings shown.




**Step 8:** Attach the secondary knee braces (8) to the Roof Trusses with 3/8" x 6 1/2" bolts (BL1) and to the posts with 3/8" X 9" Bolts (BL2) with washer and nuts. Check the marked numbers on each secondary knee brace and place as drawings shown.




**Step 9:** Attach the roof panels (5) to the perimeter roof trusses with 3/8" x 8" bolts (BL4) and to the central roof trusses with 3/8" x 9 1/2" bolts (BL5). Check the marked numbers on each roof panels and place as drawings shown (F-1 to F-16).




**Step 10:** Attach the roof boards to the Roof Trusses (4) with 2" deck screws (DS1).




**Step 11:** Attach the roof trims (6) to the roof trusses with 2" deck screws (DS1). Check the marked numbers on each roof trims and place as drawings shown.



**Step 12:** Attach the fascias (10) to the roof trusses with 2" deck screws (DS1). Check the marked numbers on each fascias and place as drawings shown.




**Step 13:** Attach the ceiling fan base (11) to the roof trusses with 3/8" x 10" bolts (BL6). Check the marked numbers on each fascias and place as drawings shown.





**Step 14:** Finally, attach the boots (9) to each post with 3" deck screws (DS2).



*This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.*