















FOREVER REDWOOD

From the Forest, For the Forest since 1995

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday










ASSEMBLY INSTRUCTIONS FOR THE DEL RIO CATHEDRAL CEILING THICK TIMBER PAVILION




CONTENT OF BOXES				
Qty.	Description	Drawing	No.	
Will Vary.	Posts		1	
Will Vary.	Single Supports		2	
Will Vary.	Supports with In-Between Blocking		3	
Will Vary.	Triangles		4	
Will Vary.	Secondary Knee Braces		5	
Will Vary.	Main Knee Braces		6	
Will Vary.	Roof Panels		7	
4	Roof Fascia's		8	
Will Vary.	Boots		9	
Will Vary.	Standard, Gale Wind or Hurricane Anchors Bases. If ordered.		Standard	
			Gale Wind	
			Hurricane	
			10	

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.

HARDWARE LIST

Description	Drawing	No.
1/2" X 4" Anchor Bolts (To attach the anchor bases to the ground).		A
3/8" X 3" Lag Bolts (To attach the posts to the anchor bases)		B
3/8" X 8" Bolts (To attach the single supports and the triangles to the posts. / To attach the supports together. / To attach the secondary knee braces to the triangles. / To attach the main knee braces to the supports).		C
3" Deck screws (To attach the triangles to the supports. / To attach the roof panels together).		D
3/8" X 12" Bolts (To attach the knee braces to the posts).		E
3/8" X 16" Bolts (To attach the knee braces to posts).		F
3/8" X 9 1/2" Bolts (To attach the roof panels to the triangles).		G
3/8" X 11" Bolts (To attach the roof panels to the triangles).		H
2" Deck Screws (To attach the roof panels to the triangles. / To attach the roof fascias to the roof panels. / To attach the boots to the posts).		I

Note: Dimensions of your hardware will vary depending on size.




DESCRIPTION	No
Posts	1
Single Supports	2
Supports with In-Between Blocking	3
Triangles	4
Secondary Knee Braces	5
Main Knee Braces	6
Roof Panels	7
Roof Fascia's	8
Boots	9
Anchor Bases	10


Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.

NOTE: In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).

Step 1: Install the anchor base (10) with $\frac{1}{2}$ " X 4" anchor bolts (A) or lag bolts. Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases (10). Drill a $\phi \frac{1}{4}$ " hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use a $\frac{5}{16}$ " X 3" lag bolts (B) to attach each post to the its respective anchor base (10).




Step 2: First attach the single supports (2) to the posts with 3/8" X 8" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 3: Put up the supports with in-between blocking (3), into the post notches as shown and attach to the posts with the single support bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 4: Attach the single supports to the supports with in-between blocking, use 3/8" x 8" bolts (C). The quantity of bolts depends on the length of the supports.




Step 5: Attach the triangles (4) to the posts with 3/8" x 8" bolts (C) and to the supports with 8" x 3" deck screws (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 6: Attach the central triangles (4) to the supports with 8'' x 3'' deck screws (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 7: Attach the secondary knee braces (5) to the posts with 3/8'' x 12'' bolts (E) and to the triangles with 3/8'' x 8'' Bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 8: Attach the main knee braces (6) to the posts with 3/8" x 12" bolts (E) and 3/8" x 16" bolts (F). After that, attach to the supports with 3/8" x 8" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 9: Use 3/8" x 9 1/2" bolts (G) to attach the roof panels (7) to the perimeter triangles and 3/8" x 11" bolts (H) to attach the roof panels (7) to the central triangles, as shown below. Each part has a series of numbers that indicate where to attach the part with the corresponding number.





Step 10: Attach the roof panels (7) to the triangles with 2'' deck screws (I). The roof panels will be attached together with 3'' deck screws (D), as shown below.



Step 11: Attach the roof fascia's (8) to the roof panels with 2'' deck screws (I). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 12: Finally, attach the boots (9) to each post with 8" x 3" deck screws (D).





This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you