



# FOREVER REDWOOD

*From the Forest, For the Forest since 1995*







---

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

## ASSEMBLY INSTRUCTIONS FOR THE HEXAGONAL PARK PAVILION












CONTENT OF BOXES			
Qty.	Description	Drawing	No.
6	Posts		1
6	Supports		2
6	Diagonal Supports		3
12	Corvels If ordered		4
1	Roof Frame		5
6	Roof Panels		6

*Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.*














CONTENT OF BOXES			
Qty.	Description	Drawing	No.
Will Vary	Roof Boards		7
6	Roof Trims		8
1	Cupola If ordered		9
5	Railings If ordered		10
6	Boots If ordered		11
6	Standard or High Wind Anchors Bases. If ordered.		12
		 High Wind Anchor Bases	


*Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.*



HARDWARE LIST		
Description	Drawing	No.
$\frac{1}{2}$ " x 4" Anchor Bolts or Lag Bolts (To attach the anchor bases to the ground). <b>If ordered standard anchor bases.</b>		A
$\frac{5}{16}$ " x 3" Lag Bolts (To attach the anchor bases to the posts. / To attach the roof panels to the roof frame. / To attach the roof panels together).		B
$\frac{3}{8}$ " x 4" Lag Bolts (To attach the supports, the corbels and the railings to the posts).		C
$\frac{5}{16}$ " x 5 $\frac{1}{2}$ " Bolts (To attach the diagonal supports to the supports).		D
$\frac{3}{8}$ " x 6" Bolts (To attach the corbels to the supports).		E
3" Deck Screws (To attach the roof panels to the roof frames. / To attach the boots to the posts).		F
$\frac{3}{8}$ " x 8" Lag Bolts (To attach the roof panels to the supports).		G
2" Deck Screws (To attach the roof boards to the roof panels).		H
4" Deck Screws (To attach the roof trims to the roof boards. / To attach the cupola to the roof frame).		I

*Note: Dimensions of your hardware will vary depending on size.*






DESCRIPTION	No
Posts	1
Supports	2
Diagonal Supports	3
Corvels	4
Roof Frame	5
Roof Panels	6
Roof Boards	7
Roof Trims	8
Cupola	9
Railings	10
Boots	11
Anchor Bases	12


*Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.*

**NOTE:** In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).


**Step 1:** Install the anchor bases (12) with ½” X 4” anchor bolts or lag bolts (A). Please see the “How to anchor your pergola document” for all details.




**Step 2:** Set your posts (1) in the saddle of the anchor bases. Drill a  $\phi$  ¼” hole prior to anchoring in each post to facilitate the ratcheting of the hardware. After that, use a 5/16” x 3” lag bolts (B) to attach each post to the anchor bases.



**Step 3:** Use 3/8" x 4" lag bolts (C) to attach the supports (2) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 4:** Attach the diagonal supports (3) to the supports with 5/16" x 5 1/2" bolts (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.






**Step 5:** Attach the corbels (4) to the supports with 3/8" x 6" bolts (E) and to the posts with 3/8" x 4" lag bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 6:** Attach the roof panels (6) to the roof frame (5) with 5/16" x 3" lag bolts (B) and 3" deck screws (F). Each part has a series of numbers that indicate where to attach the part with the corresponding number.







**Step 7:** Attach the roof panels (6) to the supports with 3/8" x 8" lag bolts (G). Then attach the roof panels together with 5/16" x 3" bolts (B). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 8:** Repeat the steps 6&7 until the installation is complete. After that, put exterior clear silicone on the roof panels joints.




**Step 9:** First, measure the roof panels. After that, cut the #30 Felt Roof Deck Protection to those measures. Use staples to attach the #30 Felt Roof Deck Protection to the roof panels.




**Step 10:** Use 2" deck screws (**H**) to attach the roof boards (**7**) to the roof panels. Put the boards from the bottom to the top, the overlapping between these boards it will be of  $\frac{3}{4}$ ". After that, put exterior clear silicone on the roof boards joints. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 11:** Use 4'' deck screws (**I**) to attach the roof trims (**8**) to the roof boards. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 12:** Insert the cupola (**9**) in the center of the roof frame. After that, use 4'' deck screws (**I**) to attach them together. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 13:** Use 3/8" x 4" lag bolts (C) to attach the railings (10) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 14:** Finally, use 3" deck screws (F) to attach the boots (11) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.





*This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.*