



FOREVER REDWOOD

From the Forest, For the Forest since 1995








866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

ASSEMBLY INSTRUCTIONS FOR THE BACKYARD CABIN





CONTENT OF BOXES







Qty.	Description	Drawing	No.
Will Vary	Floor Panels		1
	Floor Frames		2
	Posts		3
	Supports		4
	Wall Panels		5
	Wall panel with windows		6
	Wall trims		7

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.
















CONTENT OF BOXES


Qty.	Description	Drawing	No.
	Triangles		8
	Ridge Beam		9
Will Vary	Roof Panels		10
	Doors		11
	Fences		12
	Angles		13

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.

HARDWARE LIST


Description	Drawing	No.
2'' Deck Screws (To attach the floor panels together. / To attach the wall trim to the wall panels).		A
4'' Deck Screws (To attach the floor frames to the floor panels. / To attach the floor together).		B
3/8'' x 6'' Bolts (To attach the posts to the floor. / To attach the supports and the triangles to the posts. / To attach the roof panels to the ridge beam).		C
5/16'' x 4 1/2'' Lag Bolts (To attach the wall panels to the posts and to the floor).		D
3'' Deck Screws (To attach the wall panels together. / To attach the triangles to the supports. / To attach the fences).		E
5/16'' x 4'' Lag Bolts (To attach the ridge beam to the triangles).		F
3/8'' x 1 1/2'' Lag Bolts (To attach the angles to the central triangle and to the supports).		G
5/16'' x 3'' Bolts (To attach the roof panels together. / To attach the roof panels to the perimeter triangles).		H
5/16'' x 4 1/2'' Bolts (To attach the roof panels to the central triangle).		I
1 5/8'' Deck Screws (To attach the doors to the walls).		J
5/16'' x 3'' Lag Bolts (To attach the fences).		K

DESCRIPTION	No
Floor Panels	1
Floor Frames	2
Posts	3
Supports	4
Wall Panels	5
Wall panel with windows	6
Wall trims	7
Triangles	8
Ridge Beam	9
Roof Panels	10
Doors	11
Fences	12
Angles	13




Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.


Step 1: The interior floor panels (1) will be attached together with 2" deck screws (A). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 2: Attach the interior floor frames (2) to the interior floor panels with 4" deck screws (B). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 3: Repeat the steps 1 & 2 to assemble the exterior floor (1,2). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 4: Attach the exterior floor to the interior floor with 4'' deck screws (B). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 5 Attach the posts (3) to the floors with 3/8" x 6" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 6: Attach the supports (4) to the posts with 3/8" x 6" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 7: Attach the wall panels (5,6) to the floor and to the posts with 5/16" x 4 1/2" lag bolts (D). The wall panels will be attached together with 3" deck screws (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 8: Continue attaching the wall panels (5,6) until the operation is complete. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 9: Use 2'' deck screws (A) to attach the wall trims (7) to the wall panels. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 10: Attach the triangles (8) to the posts with 3/8'' x 6'' bolts (C) and to the supports with 3'' deck screws (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 11: Use 5/16" x 4" lag bolts (F) to attach the ridge beam (9) to the triangles. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 12: Use angles and 3/8" x 1 1/2" lag bolts (G) to attach the central triangle to the supports. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 13: Attach the roof panels (10) to the ridge beam with 3/8" x 6" bolts (C). The roof panels will be attached together with 5/16" x 3" bolts (H). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 14: Attach the roof panels (10) to the perimeter triangles with 5/16" x 3" bolts (H) and to the central triangle with 5/16" x 4 1/2" bolts (I). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 15: Use 1 5/8" deck screws (**J**) to attach the doors (**11**) to the walls. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 16: Finally, use 5/16" x 3" lag bolts (**K**) and 3" deck screws (**E**) to attach the fences (**12**). Attach the part has a series of numbers that indicate where to attach the part with the corresponding number.





This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.