

# FOREVER REDWOOD









*From the Forest, For the Forest since 1995*

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

## ASSEMBLY INSTRUCTIONS FOR KIKUE'S PAVILION














CONTENT OF BOXES			
Qty.	Description	Drawing	No.
	Posts		1
	Supports with In-Between Blocking		2
	Single Supports		3
	Diagonal Rafters		4
	Cupola Frame		5
Will Vary	Roof Panels		6
	Roof Boards		7
	Roof Trims		8









*Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.*










CONTENT OF BOXES			
Qty.	Description	Drawing	No.
Will Vary	Cupola		9
	Cupola Tip		10
	T-Supports Covers- A		11
	T-Supports Covers- B		12
	Boots <b>If ordered</b>		13
	Standard, Gale Wind or Hurricane Anchor Bases <b>If ordered</b>		14
		 Hurricane	
	Metal Plaques		15
	T-Supports		16

***Note:** Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.*

## HARDWARE LIST


Description	Drawing	No.
$\frac{1}{2}$ " x 4" Anchor Bolts (To attach the anchor bases to the ground).		A
$\frac{5}{16}$ " x 3" Lag Bolts (To attach the anchor bases to the posts).		B
$\frac{3}{8}$ " x 10" Lag Bolts (To attach the supports to the posts. / To attach the supports together).		C
$\frac{3}{8}$ " x 4" Lag Bolts (To attach the supports together).		D
$\frac{3}{8}$ " x 7" Bolts (To attach the supports together).		E
$\frac{3}{8}$ " x 3" Lag Bolts (To attach the metal plaques to the supports. To attach the T-Supports to the posts and to the supports).		F
$\frac{5}{16}$ " x 3 $\frac{1}{2}$ " Bolts (To attach the diagonal rafters to the metal plaques).		G
$\frac{3}{8}$ " x 3 $\frac{1}{2}$ " Lag Bolts (To attach the roof panels to the diagonal rafters).		H



HARDWARE LIST		
Description	Drawing	No.
5/16" x 3" Bolts (To attach the roof panels together).		I
2 1/2" Deck Screws (To attach the roof boards to the roof panels).		J
3/8" x 8" Lag Bolts (To attach the roof trims to the roof panels).		K
3/8" x 12" Lag Bolts (To attach the roof trims to the roof panels).		L
4" Deck Screws (To attach the cupola to the cupola frame).		M
2" Deck Screws (To attach the T-Support Covers to the posts and to the supports).		N
3" Deck Screws (To attach the boots to the posts).		O








DESCRIPTION	No
Posts	1
Supports with In-Between Blocking	2
Single Supports	3
Diagonal Rafters	4
Cupola Frame	5
Roof Panels	6
Roof Boards	7
Roof Trims	8
Cupola	9
Cupola Tip	10
T-Supports Covers- A	11
T-Supports Covers- B	12
Boots	13
Anchor Bases	14
Metal Plaques	15
T-Supports	16


*Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.*

**NOTE:** In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).


**Step 1:** Install the anchor bases (14) to the ground with  $\frac{1}{2}$ " x 4" Anchor bolts (A). Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases. Drill a  $\phi$  7/16" hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use a 5/16" X 3" lag bolts (B) to attach each post to its respective anchor base.




**Step 2:** Put up the supports with in-between blocking (2), into the post notches as shown. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 3:** Attach the single supports (3) to the posts and to the supports with in-between blocking with 3/8" X 10" lag bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 4:** Attach the single supports to the supports with in-between blocking, use 3/8" x 10" lag bolts (C) and 3/8" x 4" lag bolts (D).







**Step 5** Attach the single supports to the supports with in-between blocking, use 3/8" x 7" bolts (E)4E3.




**Step 6:** Use 3/8" x 3" lag bolts (F) to attach the metal plaques (15) to the supports. part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 6:** Use 3/8" x 3" lag bolts (F) to attach the T-Supports (16) to the posts and to the supports. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 7:** Use 5/16" x 3 1/2" bolts (G) to attach the diagonal rafters (4) to the metal plaques. After that, attach the diagonal rafters to the cupola frame (5) with 3/8" x 10" lag bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 8:** Use 3/8" x 10" Lag bolts (C) to attach the roof panels (6) to the supports and 5/16" x 3 1/2" bolts (G) to attach to the cupola frame. Each part has a series of numbers that indicate where to attach the part with the corresponding number




**Step 9:** Attach the roof panels (6) to the diagonal rafters with 3/8" x 3 1/2" lag bolts (H). The roof panels will be attached together with 5/16" x 3" bolts (I). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 10:** First, measure the roof panels. After that, cut the #30 Felt Roof Deck Protection to those measures. Use staples to attach the #30 Felt Roof Deck Protection to the roof panels.




**Step 11:** Use 2 ½" deck screws (**J**) to attach the roof boards (**7**) to the roof panels. Put the boards from the bottom to the top, the overlapping between these boards will be of ¾". Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 12:** Attach the roof trims (8) to the roof panels with 3/8" x 8" lag bolts (K), 3/8" x 10" lag bolts (C) and 3/8" x 12" lag bolts (L), as shown below. Each part has a series of numbers that indicate where to attach the part with the corresponding number




**Step 13:** Attach the cupola (9) to the cupola frame with 4" deck screws (M). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 14:** Place the cupola tip (10) on the cupola.





**Step 15:** Use 2" deck screws (N) to attach the T-Support covers (11,12) to the supports and to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.





**Step 16:** Finally, use 3" deck screws (O) to attach the boots (13) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.





*This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.*