



FOREVER REDWOOD













From the Forest, For the Forest since 1995

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

ASSEMBLY INSTRUCTIONS FOR THE MARIN OUTDOOR KITCHEN PERGOLA













CONTENT OF BOXES				
Qty.	Description	Drawing		No.
4	Posts			1
2	Single Supports			2
2	Supports with In-Between Blocking			3
Quantity will vary	Arched Rafters			4
6	Main Knee Braces			5
4	Long Secondary Knee Braces			6
4	Short Secondary Knee Braces			7
Quantity will vary	Slats			8
4	Boots			9
4	Standard, Gale Wind or Hurricane Anchors Bases. If ordered.		Standard	10
			Gale Wind	
			Hurricane	


Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.



HARDWARE LIST		
Description	Drawing	No.
$\frac{1}{2}$ " X 3 $\frac{1}{2}$ " Anchor Bolts (To attach the anchor bases to the ground).		A
$\frac{5}{16}$ " X 3" Lag Bolts (To attach the anchor bases to the post).		B
$\frac{3}{8}$ " X 7" Bolts (To attach the supports to the posts. / To attach the supports together. / To attach the main knee braces to the supports).		C
$\frac{3}{8}$ " X 6" Bolts (To attach the arched rafters to the posts).		D
3" Deck Screws (To attach the arched rafters to the supports. / To attach the slats to the arched rafters. / To attach the boots to the posts).		E
$\frac{3}{8}$ " X 8" Bolts (To attach the main knee braces to the posts).		F
$\frac{3}{8}$ " X 10" Bolts (To attach the knee braces to the posts).		G
$\frac{3}{8}$ " X 5" Bolts (To attach the secondary knee braces to the arched rafters).		H

Note: Dimensions of your hardware will vary depending on size.






DESCRIPTION	No.
Posts	1
Single Supports	2
Supports with In-Between Blocking	3
Arched Rafters	4
Main Knee Braces	5
Long Secondary Knee Braces	6
Short Secondary Knee Braces	7
Slats	8
Boots	9
Anchors Bases	10


Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.

NOTE: In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).


Step 1: Install the anchor bases (10) with $\frac{1}{2}$ " X $3\frac{1}{2}$ " anchor bolts (A) or lag bolts. Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases. Drill a $\phi \frac{1}{4}$ " hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use a $\frac{5}{16}$ " X 3" lag bolts (B) to attach each post to its respective anchor base.




Step 2: First attach the single supports (2) to the posts with $\frac{3}{8}$ " X 7" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 3: Place the supports with in-between blocking (3), into the post notches as shown and attach to the post with the single support bolts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 4: Attach the single supports (2) to the supports with in-between blocking (3), use 3/8" X 7" bolts (C). The quantity of bolts depends on the length of the supports.




Step 5: Attach the perimeter arched rafters first (4) to the posts with 3/8" x 6" bolts (D) and to the supports with 8" x 3" deck screws (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 6: Attach the main knee braces (5) to the supports with 3/8" x 7" bolts (C). After that, use 3/8" x 8" bolts (F) and 3/8" x 10" bolts (G) to attach to the posts, as shown below. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 7: Attach the secondary knee braces (6,7) to the posts with 3/8" x 10" bolts (G) and to the arched rafters with 3/8" x 5" bolts (H). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 8: Use 8" x 3" deck screws (E) to attach the other arched rafters (4) to the supports. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 9: Attach the slats (8) to the arched rafters with 3" deck screws (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



10: Finally, attach the boots (9) to the posts with 8" x 3" deck screws (E).







This completes the Pergola assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.

HOW TO REMOVE THE ELECTRICAL WIRING TRIM FROM THE POST?


Step 1: First remove the deck screws to remove the boots of the post.




Step 2: Loosen the nut on the bolt support.



Step 3: The bolt of the post and the brace must be flush with the post.



Step 4: Swing the brace aside. After that, remove the trim.



Note: The dimensions of the trim are standard, adjust if necessary.