




866.332.2403 (Toll Free); 7am-7pm Pacific Time, Monday-Saturday

Assembly instructions for: **PATIO PAVILIONS**



CONTENT OF BOXES

| QUANTITY | DESCRIPTION | DRAWING | |
|--------------------------------------|---------------------------------|--|---|
| 5 | Wall panels |  | |
| 1 | Door frame |  | |
| Quantity will vary depending on size | Roof panels |  | |
| Quantity will vary depending on size | Rafters |  | |
| Quantity will vary depending on size | Roof trims |  | |
| 1 | Cupula |  | |
| If you ordered. | Floor panels |  | |
| Depending on size | Hardware: Bolts and deck screws | Deck Screws | Bolts, washers and nuts |
| | |  |  |

ASSEMBLY INSTRUCTIONS

All Gazebos are completely erected in the shop prior to crating for shipping. All hardware is included. All parts are fully sanded, routed, notched, drilled and numbered for ease of reassembly. The parts that go together have the same numbers/letters written next to the predrilled holes they attach to.

All Gazebos parts are notched into the part they connect to. You'll find the numbers next to the notches and/or drill holes. Before beginning re-assembly, place the parts that go together on the ground with one another so you don't have to be searching around in the middle of the reassembly. Most Gazebos take less than one day to reassemble with one helper.

Note: print the drawings that you approved before start the construction, they are needed to see the distances between the posts.


STEP 1: SEE FOLLOWING SECTION ONLY IF YOUR GAZEBO WAS ORDERED WITH THE INTERIOR FLOORING OPTION.

When you are ready to install your Pavilion make sure the ground is leveled. If your Gazebo is going to be installed over concrete, you must attach the anchors the concrete.

Attach each one the floor sections to one another with four deck screws (3"x #8). As shown:




STEP 2: Attach the wall panel to the other wall panel and floor with deck screws (3"x #8). (Match up the numbers to attach the two parts together).



STEP 3: Attach the door frame to the wall panels with deck screws 3" x #8.



STEP 4: Attach the timbers together to form the base of the roof with bolts, washers & nuts. (Match up the numbers to attach the two parts together). Tap the bolt all the way into the wood to set it. Then add a washer and nut and lightly tighten.



STEP 5: Attach the rafters to the roof base and small center base with bolts washers & nuts. (Match up the numbers to attach the two parts together). Tap the bolt all the way into the wood to set it. Then add a washer and nut and lightly tighten.



STEP 6. Attach the Roof panel to the rafters with six decks crews (3"x #8). And repeat the process with each panel roof panel.

Note: Not put all the roof panels, just as the second photo.



STEP 7: Insert the cupula in the small center base and then continue putting the rest of roof panels.



STEP 8. Attach the roof trim between each roof panel with three deck screws (3"x #8). And repeat the process for each space between the installed roof panels and fill between gaps with silicone.





Thank you. If you have any questions, please call or email us.