



# FOREVER REDWOOD







*From the Forest, For the Forest since 1995*

---









866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday

## ASSEMBLY INSTRUCTIONS FOR THE **THE GRANADA PAVILION**



CONTENT OF BOXES			
Qty.	Description	Drawing	No.
Will Vary.	Posts		1
	Supports		2
	Knee Braces		3
	Triangles		4
	Roof Beam		5
	Rafters		6

*Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.*

CONTENT OF BOXES				
Qty.	Description	Drawing		No.
Will Vary.	Roof Boards			7
	Boots <b>If ordered</b>			8
	Ceiling Fan Bases <b>If ordered</b>			9
		To Triangles	To Rafters	
	Curtain Rods <b>If ordered</b>			10
	Standard, Gale Wind or Hurricane Anchors Bases. <b>If ordered.</b>			11
		Standard	Gale Wind	
	Curtain Rod Bases <b>If ordered</b>			12

*Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.*




HARDWARE LIST		
Description	Drawing	No.
1/2" X 3 1/2" Anchor Bolts (To attach the anchor bases to the ground).		A
5/16" X 3" Lag Bolts (To attach the anchor bases to the posts).		B
3/8" X 7" Bolts (To attach the supports to the posts).		C
3/8" X 10" Bolts (To attach the knee braces to the supports and to the posts).		D
3/8" X 10" Lag Bolts (To attach the triangles and the rafters to the supports).		E
3/8" X 6" Lag Bolts (To attach the triangles and the rafters to the roof beam).		F
5/16" X 4" Lag Bolts (To attach the perimeter rafters to the beam).		G
6" X 2" Deck Screws (To attach the roof boards to the rafters and to the triangles).		H
8" X 3" Deck Screws (To attach the boots to the posts).		I
3/8" X 12" Bolts (To attach the ceiling fan bases to the triangles).		J
5/16" X 4 1/2" Bolts (To attach the ceiling fan bases to the rafters).		K
6 X 2 1/2" Deck Screw (To attach the curtain rod bases to the posts).		L

*Note: Dimensions of your hardware will vary depending on size.*








DESCRIPTION	No
Posts	1
Supports	2
Knee Braces	3
Triangles	4
Roof Beam	5
Rafters	6
Roof Boards	7
Boots	8
Ceiling Fan Bases	9
Curtain Rods	10
Anchors Bases	11
Curtain Rod Bases	12

*Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.*


**NOTE:** In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).

**Step 1:** Install the anchor bases (11) with  $\frac{1}{2}$ " X  $3\frac{1}{2}$ " anchor bolts or lag bolts (A). Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases. Drill a  $\phi\frac{1}{4}$ " hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use a  $\frac{5}{16}$ " X 3" lag bolts (B) to attach each post to its respective anchor base.




*All options of posts (No posts decorative trim, vertical posts decorative trim and horizontal posts decorative trim) will be installed in the same way.*


**Step 2:** Attach the supports (2) to the posts with  $\frac{3}{8}$ " x 7" bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number




**Step 3:** Use 3/8" x 10" bolts (D) to attach the knee braces (3) to the supports and to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number




**Step 4:** Attach the triangles (4) to the supports with 3/8" x 10" lag bolts (E). Each part has a series of numbers that indicate where to attach the part with the corresponding number



**Step 5:** Place the roof beam (5), into the triangle notches as shown. After that, use 3/8" x 6" lag bolts (F) to attach the triangles to the roof beam. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 6:** Attach the central rafters (6) to the supports with 3/8" x 10" lag bolts (E) and to the roof beam with 3/8" x 6" lag bolts (F). Each part has a series of numbers that indicate where to attach the part with the corresponding number.







**Step 7:** Attach the perimeter rafters (6) to the supports with 3/8" x 10" lag bolts (E) and to the roof beam with 5/16" x 4" lag bolts (G). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 8:** Use 6" x 2" deck screws (H) to attach the roof boards (7) to the rafters and to the triangles. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 9:** Attach the boots (8) to the posts with 8" x 3" deck screws (I).




**Step 10:** Use 3/8" x 12" bolts (J) to attach the central ceiling fan base (9) to the central triangle. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




**Step 11:** Attach the perimeter ceiling fan bases (9) to the rafters with 5/16" x 4 1/2" bolts (K). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 12:** Use 6" x 2 1/2" deck screws (L) to attach the curtain rod bases (12) to the posts. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



**Step 13:** Place the curtain rods (10) on the curtain rod bases.







*This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.*