



FOREVER REDWOOD
















From the Forest, For the Forest since 1995

866.332.2403 (TOLL FREE); 7am – 7pm Pacific Time, Monday-Saturday







ASSEMBLY INSTRUCTIONS FOR THE LORETO PAVILION











| CONTENT OF BOXES | | | | |
|---------------------|---|---|---|--|
| Qty. | Description | Drawing | | No. |
| 4 | Posts |  | | 1 |
| 4 | Single Supports |  | | 2 |
| 4 | Supports with In-Between Blocking |  | | 3 |
| 4 | Arcs |  | | 4 |
| 1 | Second Frame |  | | 5 |
| 4 | Central Rafters |  | | 6 |
| 4 | Diagonal Rafters |  | | 7 |
| Quantity will vary. | Rafters |  | | 8 |
| 4 | Fascia's Board |  | | 9 |
| Quantity will vary. | Roof Boards |  | | 10 |
| 4 | Boots |  | | 11 |
| 4 | Metal Plaques |  | | 12 |
| 4 | Standard, Gale Wind or Hurricane Anchors Bases. If ordered. |  |  |  Hurricane |
| | | Standard | Gale Wind | |

Note: Part numbers in the Content of Boxes Table are for reference only. These do not match to the numbers marked on the parts sent.


| HARDWARE LIST | | |
|--|---|-----|
| Description | Drawing | No. |
| <p>1/2" X 4" Anchor Bolts (To attach the anchor bases to the ground).</p> |  | A |
| <p>5/16" X 3" Lag Bolts (To attach the anchor bases to the post / o attach the arcs to the supports with in-between blocking / To attach the metal plaques to the supports).</p> |  | B |
| <p>3/8" X 6" Lag Bolts (To attach the supports / To attach the diagonal rafters to the second frame).</p> |  | C |
| <p>3/8" X 10" Lag Bolts (To attach the single supports to the supports with in-between blocking and to the posts / To attach the central rafters to the single supports).</p> |  | D |
| <p>3/8" X 7 1/2" Bolts (To attach the single supports to the supports with in-*between blocking).</p> |  | E |
| <p>3/8" X 7" Bolts (To attach the arcs to the posts).</p> |  | F |

Note: Dimensions of your hardware will vary depending on size.



| HARDWARE LIST | | |
|---|--|-----|
| Description | Drawing | No. |
| 3/8'' X 15'' Bolts (To attach the arcs to the supports with in-between blocking). |  | G |
| 5/16'' X 3 1/2'' Bolts (To attach the diagonal rafters to the metal plaques). |  | H |
| 5/16'' X 4'' Bolts (To attach the central rafters to the second frame). |  | I |
| 8'' X 3'' Deck Screws (To attach the rafters to the diagonal rafters and to the single supports). |  | J |
| 1 5/8'' X 6'' Deck Screws (To attach the roof boards). |  | K |
| 2 1/2'' X 8'' Deck Screws (To attach the fascia's board to the rafters, central rafters and diagonal rafters). |  | L |

Note: Dimensions of your hardware will vary depending on size.




| DESCRIPTION | No |
|-----------------------------------|----|
| Posts | 1 |
| Single Supports | 2 |
| Supports with In-Between Blocking | 3 |
| Arcs | 4 |
| Second Frame | 5 |
| Central Rafters | 6 |
| Diagonal Rafters | 7 |
| Rafters | 8 |
| Fascia's Board | 9 |
| Roof Boards | 10 |
| Boots | 11 |
| Metal Plaques | 12 |
| Anchor Bases | 13 |


Note: Part numbers in the Drawing are for reference only. These do not match to the numbers marked on the parts sent.

NOTE: In order to know where the post needs to be placed, check the numbers on them. If the post is not marked, then place the single Supports on the ground to locate the markings for each post position and clearly set your bearings. (“Don’t attach yet, only place them on the ground to begin with”).


Step 1: Install the anchor base (13) with $\frac{1}{2}$ " X 4" anchor bolts (A) or lag bolts. Please see the “How to anchor your pergola document” for all details. Set your post (1) in the saddle of the anchor bases (13). Drill a $\phi \frac{1}{4}$ " hole in the post prior to anchoring to facilitate the ratcheting of the hardware. After that, use a $\frac{5}{16}$ " X 3" lag bolts (B) to attach each post to the its respective anchor base (13).




Step 2: Attach the single supports (2) to the posts with $\frac{3}{8}$ " X 6" lag bolts (C). Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 3: Use 3/8" x 6" lag bolts (C) to attach the supports with in-between blocking (3) to the single supports. After that, use 3/8" x 10" lag bolts (D) to attach the supports with in between (3) to the posts and to the single supports. Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 4: Attach the single supports (2) to the supports with in-between blocking (3) with 3/8" x 7 1/2" bolts (E).




Step 5: Attach the arcs (4) to each post with 3/8" x 7" bolts (F).

Step 5.1: Use 5/16" x 3" lag bolts (B) to attach the arcs (4) to each supports with in-between blocking (3).


Step 5.2: Use 3/8" x 15" bolts (G) to attach the arcs (4) to each supports with in-between blocking (3). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 6: Attach the metal plaques (12) to the supports at their corner (2,3) with 5/16" x 3" lag bolts (B).




Step 7: Attach a diagonal rafter (7) to the second frame (5) with 3/8" x 6" lag bolts (C). After that, attach to its metal plaques (12) with 5/16" x 3 1/2" bolts (H). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 8: Attach the rest diagonal rafters (7) to the second frame (5) with 3/8" x 6" lag bolts (C) and to the rest metal plaques (12) with 5/16" x 3 1/2" bolts (H). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 9: Attach the central rafters (6) to the second frame (5) with 5/16" x 4" lag bolts (I) and to the single supports (2) with 3/8" x 10" lag bolts (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 10: Attach the rafters (8) to the diagonal rafters (7) with 3" deck screws (J) and to the single supports with 3/8" x 10" lag bolts (D). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 11: Attach the rest rafters (8) to the diagonal rafters and to the single supports (2) with 3'' deck screws (J). Each part has a series of numbers that indicate where to attach the part with the corresponding number.




Step 12: Use 8'' x 2 1/2'' deck screws (L) to attach the fascia boards (9) to the rafters, central rafters and diagonal rafters. Each part has a series of numbers that indicate where to attach the part with the corresponding number.



Step 13: Use 1 5/8" x 6" deck screws (**K**) to attach the roof boards (**10**) to the rafters, central rafters and diagonal rafters. Put the boards from the bottom to the top. Each part has a series of numbers that indicate where to attach the part with the corresponding number



Step 14: Finally, use 3" deck screws (**J**) to attach the boots (**11**) to each posts.







This completes the Pavilion assembly. Hope you enjoy your set for many decades. If you ever have a problem or a question, don't hesitate to call us (866 332 2403) or email us. We are here to support you.

HOW TO REMOVE THE ELECTRICAL WIRING TRIM FROM THE POST:



Step 1: First remove the deck screws to remove the boots of the post.



Step 2: Remove the arcs of the Pavilion.



Step 3: Remove the trim.



***Note:** The dimensions of the trim are standard, adjust if necessary.*